

# Engine Workshop Manual 13B-MSP (Multi Side Port)

## FOREWORD

This manual explains the disassembly, inspection, repair, and reassembly procedures for the above-indicated engine.

In order to do these procedures safely, quickly, and correctly, you must first read this manual and any other relevant service materials carefully.

The information in this manual is current up to October, 2008. Any changes that occur after that time will not be reflected in this particular manual. Therefore, the contents of this manual may not exactly match the mechanism that you are currently servicing.

**Mazda Motor Corporation  
HIROSHIMA, JAPAN**

## CONTENTS

Title	Section
<b>GENERAL INFORMATION</b>	<b>00</b>
<b>ENGINE</b>	<b>01</b>

© 2008 Mazda Motor Corporation  
PRINTED IN U.S.A., OCTOBER 2008  
Form No. 1773-1U-03C  
Part No. 9999-95-E13B-MSP09

# GENERAL INFORMATION

**00**  
SECTION

00-00

## GENERAL INFORMATION . . . . 00-00

### 00-00 GENERAL INFORMATION

<b>HOW TO USE THIS MANUAL</b> . . . . .	00-00-1	Inspection During Removal,	
Range of Topics . . . . .	00-00-1	Disassembly . . . . .	00-00-6
Service Procedure . . . . .	00-00-2	Arrangement of Parts . . . . .	00-00-7
Symbols . . . . .	00-00-4	Cleaning of Parts . . . . .	00-00-7
Advisory Messages . . . . .	00-00-4	Reassembly . . . . .	00-00-7
<b>UNITS</b> . . . . .	00-00-5	Adjustment . . . . .	00-00-8
Conversion to SI Units		Rubber Parts and Tubing . . . . .	00-00-8
(Système International d'Unités) . . . . .	00-00-5	Hose Clamps . . . . .	00-00-8
Rounding Off . . . . .	00-00-5	Torque Formulas . . . . .	00-00-8
Upper and Lower Limits . . . . .	00-00-5	Vise . . . . .	00-00-9
<b>FUNDAMENTAL PROCEDURES</b> . . . . .	00-00-6	<b>ELECTRICAL SYSTEM</b> . . . . .	00-00-9
Preparation of Tools and Measuring		Connectors . . . . .	00-00-9
Equipment . . . . .	00-00-6	<b>SAE STANDARDS</b> . . . . .	00-00-11
Special Service Tools . . . . .	00-00-6	<b>ABBREVIATIONS</b> . . . . .	00-00-11
Disassembly . . . . .	00-00-6	<b>IDENTIFYING SPECIFICATION</b> . . . . .	00-00-12

#### HOW TO USE THIS MANUAL

CHU00000001E01

##### Range of Topics


- This manual contains procedures for performing all required service operations. The procedures are divided into the following five basic operations:
  - Removal/Installation
  - Disassembly/Assembly
  - Replacement
  - Inspection
  - Adjustment
- Simple operations which can be performed easily just by looking at the vehicle (i.e., removal/installation of parts, jacking, vehicle lifting, cleaning of parts, and visual inspection) have been omitted.

## GENERAL INFORMATION

### Service Procedure

#### Inspection, adjustment

- Inspection and adjustment procedures are divided into steps. Important points regarding the location and contents of the procedures are explained in detail and shown in the illustrations.



WGIWXX0009E

# GENERAL INFORMATION

00-00

## Repair procedure

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual part inspection. However, only removal/installation procedures that need to be performed methodically have written instructions.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration. In addition, symbols indicating parts requiring the use of special service tools or equivalent are also shown.
3. Procedure steps are numbered and the part that is the main point of that procedure is shown in the illustration with the corresponding number. Occasionally, there are important points or additional information concerning a procedure. Refer to this information when servicing the related part.

**SHOWS SERVICE ITEM(S)**

**Procedure**

**“Removal/Installation” Portion**

**“Inspection After Installation” Portion**

**FRONT UPPER LINK, FRONT UPPER LEADING LINK REMOVAL/INSTALLATION**

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the splash shield(s). (See 09-11-11 SPLASH SHIELD INSTALLATION.)
3. Remove in the order indicated in the table.
4. Install reverse order of removal.
5. Inspect the front wheel alignment and adjust it if necessary.

**INDICATES RELEVANT REFERENCES THAT NEED TO BE FOLLOWED DURING INSTALLATION**

**SHOWS SPECIAL SERVICE TOOL (SST) FOR SERVICE OPERATION**

**SHOWS APPLICATION POINTS OF GREASE, ETC.**

**SHOWS EXPENDABLE PARTS**

**SHOWS DETAILS**

**SHOWS TIGHTENING TORQUE SPECIFICATIONS**

**SHOWS TIGHTENING TORQUE UNITS**

**SHOWS REFERRAL NOTES FOR SERVICE**

**SHOWS REFERRAL NOTES FOR SERVICE**

**SHOWS SPECIAL SERVICE TOOL (SST) NO.**

**KNUCKLE**

**UPPER LEADING LINK**

**UPPER LATERAL LINK**

**94-116 (9.5-11.9, 69-86)**

**43-56 (4.3-5.8, 32-41)**

**44-53 (4.4-5.5, 32-39)**

**79-107 (8.0-11.0, 58-79)**

**N-m (kgf-m, ft.lbf)**

1	Split pin	5	Adjust cam bolt
2	Nut	6	Upper lateral link
3	Upper lateral link ball joint	7	Dust boot, clip (upper lateral link)
(See 02-13-6 Upper Lateral Link Ball Joint Removal Note)		8	Split pin
4	Cam nut, cam plate	9	Nut
		10	Upper leading link ball joint
		11	Upper leading link
		12	Dust boot (upper leading link)

**INSTALL THE PARTS BY PERFORMING STEPS 1-3 IN REVERSE ORDER**









**SHOWS PROCEDURE ORDER FOR SERVICE**

YLU000WA0

## GENERAL INFORMATION

### Symbols

- There are eight symbols indicating oil, grease, fluids, sealant, and the use of **SST** or equivalent. These symbols show application points or use of these materials during service.

Symbol	Meaning	Kind
	Apply oil	New appropriate engine oil or gear oil
	Apply brake fluid	New appropriate brake fluid
	Apply automatic transaxle/transmission fluid	New appropriate automatic transaxle/transmission fluid
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly
	Replace part	O-ring, gasket, etc.
	Use SST or equivalent	Appropriate tools

### Advisory Messages

- You will find several **Warnings**, **Cautions**, **Notes**, **Specifications** and **Upper and Lower Limits** in this manual.

### Warning

- A Warning indicates a situation in which serious injury or death could result if the warning is ignored.

### Caution

- A Caution indicates a situation in which damage to the vehicle or parts could result if the caution is ignored.

### Note

- A Note provides added information that will help you to complete a particular procedure.

### Specification

- The values indicate the allowable range when performing inspections or adjustments.

### Upper and lower limits

- The values indicate the upper and lower limits that must not be exceeded when performing inspections or adjustments.

# GENERAL INFORMATION

CHU000000002E01

00-00

## UNITS

Electric current	A (ampere)
Electric power	W (watt)
Electric resistance	ohm
Electric voltage	V (volt)
Length	mm (millimeter)
	in (inch)
Negative pressure	kPa (kilo pascal)
	mmHg (millimeters of mercury)
	inHg (inches of mercury)
Positive pressure	kPa (kilo pascal)
	kgf/cm <sup>2</sup> (kilogram force per square centimeter)
	psi (pounds per square inch)
Number of revolutions	rpm (revolutions per minute)
Torque	N·m (Newton meter)
	kgf·m (kilogram force meter)
	kgf·cm (kilogram force centimeter)
	ft·lbf (foot pound force)
	in·lbf (inch pound force)
Volume	L (liter)
	US qt (U.S. quart)
	Imp qt (Imperial quart)
	ml (milliliter)
	cc (cubic centimeter)
	cu in (cubic inch)
	fl oz (fluid ounce)
Weight	g (gram)
	oz (ounce)

### Conversion to SI Units (Système International d'Unités)

- All numerical values in this manual are based on SI units. Numbers shown in conventional units are converted from these values.

### Rounding Off

- Converted values are rounded off to the same number of places as the SI unit value. For example, if the SI unit value is 17.2 and the value after conversion is 37.84, the converted value will be rounded off to 37.8.

### Upper and Lower Limits

- When the data indicates upper and lower limits, the converted values are rounded down if the SI unit value is an upper limit and rounded up if the SI unit value is a lower limit. Therefore, converted values for the same SI unit value may differ after conversion. For example, consider 2.7 kgf/cm<sup>2</sup> in the following specifications:

**210—260 kPa {2.1—2.7 kgf/cm<sup>2</sup>, 30—38 psi}**  
**270—310 kPa {2.7—3.2 kgf/cm<sup>2</sup>, 39—45 psi}**

- The actual converted values for 2.7 kgf/cm<sup>2</sup> are 264 kPa and 38.4 psi. In the first specification, 2.7 is used as an upper limit, so the converted values are rounded down to 260 and 38. In the second specification, 2.7 is used as a lower limit, so the converted values are rounded up to 270 and 39.


# GENERAL INFORMATION

## FUNDAMENTAL PROCEDURES

CHU00000004E01

### Preparation of Tools and Measuring Equipment


- Be sure that all necessary tools and measuring equipment are available before starting any work.



CHU0014W003

### Special Service Tools


- Use special service tools or equivalent when they are required.



WGIWXX0024E

### Disassembly


- If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be marked in a place that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



WGIWXX0027E

### Inspection During Removal, Disassembly

- When removed, each part should be carefully inspected for malfunction, deformation, damage and other problems.




WGIWXX0028E

## GENERAL INFORMATION

### Arrangement of Parts

- All disassembled parts should be carefully arranged for reassembly.
- Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.



WGIWXX0029E


00-00

### Cleaning of Parts

- All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.

#### Warning


- **Using compressed air can cause dirt and other particles to fly out causing injury to the eyes. Wear protective eye wear whenever using compressed air.**




WGIWXX0030E

### Reassembly

- Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts.
- If removed, the following parts should be replaced with new ones:
  - Oil seals
  - Gaskets
  - O-rings
  - Lock washers
  - Cotter pins
  - Nylon nuts
- Depending on location:
  - Sealant and gaskets, or both, should be applied to specified locations. When sealant is applied, parts should be installed before sealant hardens to prevent leakage.
  - Oil should be applied to the moving components of parts.
  - Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.



WGIWXX0031E




CHU0014W006

## GENERAL INFORMATION

### Adjustment


- Use suitable gauges and testers when making adjustments.



CHU0014W005

### Rubber Parts and Tubing


- Prevent gasoline or oil from getting on rubber parts or tubing.



WGIWXX0034E

### Hose Clamps

- When reinstalling, position the hose clamp in the original location on the hose and squeeze the clamp lightly with large pliers to ensure a good fit.




WGIWXX0035E

### Torque Formulas

- When using a torque wrench-**SST** or equivalent combination, the written torque must be recalculated due to the extra length that the **SST** or equivalent adds to the torque wrench. Recalculate the torque by using the following formulas. Choose the formula that applies to you.

Torque Unit	Formula
N·m	$N \cdot m \times [L / (L + A)]$
kgf·m	$kgf \cdot m \times [L / (L + A)]$
kgf·cm	$kgf \cdot cm \times [L / (L + A)]$
ft·lbf	$ft \cdot lbf \times [L / (L + A)]$
in·lbf	$in \cdot lbf \times [L / (L + A)]$




WGIWXX0036E

A : The length of the **SST** past the torque wrench drive.  
 L : The length of the torque wrench.

# GENERAL INFORMATION

## Vise

- When using a vise, put protective plates in the jaws of the vise to prevent damage to parts.




CHU0014W010

## ELECTRICAL SYSTEM

### Connectors


#### Disconnecting connectors

- When disconnecting connector, grasp the connectors, not the wires.




CHU0000W014

- Connectors can be disconnected by pressing or pulling the lock lever as shown.



#### Locking connector

- When locking connectors, listen for a click indicating they are securely locked.



WGIWXX0043E


## GENERAL INFORMATION

### Inspection


- When a tester is used to inspect for continuity or measuring voltage, insert the tester probe from the wiring harness side.
- Inspect the terminals of waterproof connectors from the connector side since they cannot be accessed from the wiring harness side.

### Caution

- To prevent damage to the terminal, wrap a thin wire around the tester probe before inserting into terminal.



CHU0000W011



CHU0000W012

**GENERAL INFORMATION**

**SAE STANDARDS**

CHU000000003E02

- In accordance with new regulations, SAE (Society of Automotive Engineers) standard names and abbreviations are now used in this manual. The table below lists the names and abbreviations that have been used in Mazda manuals up to now and their SAE equivalents.

SAE Standard		Remark	SAE Standard		Remark
Abbreviation	Name		Abbreviation	Name	
AP	Accelerator Pedal		MAP	Manifold Absolute Pressure	
APP	Accelerator Pedal Position		MAF	Mass Air Flow	
ACL	Air Cleaner		MAF sensor	Mass Air Flow Sensor	
A/C	Air Conditioning		MFL	Multiport Fuel Injection	
A/F	Air Fuel Ratio		OBD	On-board Diagnostic System	
BARO	Barometric Pressure		OL	Open Loop	
B+	Battery Positive Voltage		OC	Oxidation Catalytic Converter	
CMP sensor	Camshaft Position Sensor		O2S	Oxygen Sensor	
LOAD	Calculated Load Value		PNP	Park/Neutral Position	
CAC	Charge Air Cooler		PID	Parameter Identification	
CLS	Closed Loop System		PSP	Power Steering Pressure	
CTP	Closed Throttle Position		PCM	Powertrain Control Module	#3
CPP	Clutch Pedal Position		PAIR	Pulsed Secondary Air Injection	Pulsed injection
CIS	Continuous Fuel Injection System		AIR	Secondary Air Injection	Injection with air pump
CKP sensor	Crankshaft Position Sensor		SAPV	Secondary Air Pulse Valve	
DLC	Data Link Connector		SFI	Sequential Multiport Fuel Injection	
DTM	Diagnostic Test Mode	#1	3GR	Third Gear	
DTC	Diagnostic Test Code(s)		TWC	Three Way Catalytic Converter	
DI	Distributor Ignition		TB	Throttle Body	
DLI	Distributorless Ignition		TP	Throttle Position	
EI	Electronic Ignition	#2	TP sensor	Throttle Position Sensor	
ECT	Engine Coolant Temperature		TCC	Torque Converter Clutch	
EM	Engine Modification		TCM	Transmission (Transaxle) Control Module	
EVAP	Evaporative Emission		TR	Transmission (Transaxle) Range	
EGR	Exhaust Gas Recirculation		TC	Turbocharger	
FC	Fan Control		VSS	Vehicle Speed Sensor	
FF	Flexible Fuel		VR	Voltage Regulator	
4GR	Fourth Gear		VAF sensor	Volume Air Flow Sensor	
GEN	Generator		WU-TWC	Warm Up Three Way Catalytic Converter	#4
GND	Ground		WOP	Wide Open Throttle	
HO2S	Heated Oxygen Sensor	With heater			
IAC	Idle Air Control				
IAT	Intake Air Temperature				
KS	Knock Sensor				
MIL	Malfunction Indicator Lamp				

#1 : Diagnostic trouble codes depend on the diagnostic test mode.

#2 : Controlled by the PCM

#3 : Device that controls engine and powertrain

#4 : Directly connected to exhaust manifold

**ABBREVIATIONS**

CHU000000011E01

AT	Automatic Transmission
MT	Manual Transmission
SST	Special Service Tool

00-00

**GENERAL INFORMATION**

**IDENTIFYING SPECIFICATION**

CHU000000000E01

- Because the engine construction varies depending on the vehicle's period of manufacture, determine the service specification by referring to the following identification.

**Identifying Specification**

	<b>Applicable VIN</b>
Type A	Except below
Type B	JM1 FE172*9# 400001— JM1 FE174*9# 400001— JM1 FE17M*9# 400001— JM1 FE17P*9# 400001—